

Bushing
Orig, Strut rod, 63-74
E22130

- A. PUSH OUT OLD TUBES AND RUBBER FROM ENDS ON STRUT ARM.
- B. CLEAN OR SANDBLAST AND PAINT STRUT ARMS WITH CAST BLAST SPRAY (#45-01) (THAT IS THE COLOR THEY WERE WHEN NEW.)
- C. PUSH ONE RUBBER IN HOLE FROM EACH SIDE.
- D. PUSH TUBE IN CENTER UNTIL IT IS CENTERED.

(INCLUDES 2 PC RUBBER BUSHING + 1 TOOTHED TUBE)